

PETZL® GRIGRI 2 BELAY Device

RESCUE

REV062823



Allows Excellent Control...

Compact, ultra-light belay device allows excellent control during the descent with assisted braking capability on all single dynamic 8.9 to 11 mm rope.

Enables one hand to hold the rope while the other utilizes the patented handle to unlock the cam for a gradual, controlled release that ensures added security when lowering a partner or rappelling.

Aluminum side plates, stainless steel cam and friction plate, reinforced nylon handle.

Features:

- Compact, ultra-light belay device featuring aluminum side plates, reinforced nylon handle, stainless steel cam and friction plate
- Excellent control during the descent with assisted braking capability on all single dynamic 8.9 to 11 mm ropes
- Enables one hand to hold the rope while the other utilizes the patented handle to unlock the cam for a gradual, controlled release of the rope
- Ensures added security when lowering a partner or rappelling

Dimensions:

- Rope Size: 8 to 11 mm
- Weight: 170 g

Petzl Belay Device

CE

ITEM #	NSN #
ZZ-0545	



NORTH AMERICAN RESCUE®

www.NARescue.com • 888.689.6277

PRODUCTS
WITH A
MISSION®