

THROW BAG 50 foot

A Necessity for Water Rescue...

Durable, easy-to-use rescue device with a highly visible orange nylon bag and mesh panels that drain quickly for use in multiple rescue operations. Packed with 50 ft of 7.5mm Pegasus Triton rope rated at 3,050 lbf. Triton rope is strong enough for multiple uses: as a throw line, tension diagonal, or a tow line for pinned kayak recovery.

The Pegasus Triton Series of ropes is specially designed for water rescue professionals and as a high quality tag line. Featuring 100% Innegra™ fiber braided core which is the lightest structure fiber available – giving Triton additional buoyancy, low elongation and consistent strength.

The sheath is made of high quality polypropylene that adds additional flotation and protection to the core. The combination of these materials give you a high strength and durable rope that is soft to the touch and can be easily stored in throw or rope bags.

Triton is also used as a tag line for rescue operations.

Features:

- Durable, easy-to-use rescue device with a highly visible orange nylon bag
- Ideal for water rescue
- Mesh panels that drain quickly for use in multiple rescue operations
- Featuring 50 ft of 7.5mm Pegasus Triton rope

Dimensions:

- L 8.5 in. x W 4.5 in. x 4.5 in.
- Weight: 1 lb 5 oz

Included:

- 50 ft. Pegasus 7.5mm Triton Rope
- 1x Nylon bag, ORG

Packed with 50 ft of 7.5mm Pegasus Triton rope rated at 3,050 lbf. Triton rope is strong enough for multiple uses: as a throw line, tension diagonal, or a tow line for pinned kayak recovery.



RESCUE

50 ft. Throw Bag

Item#

90-0064

NSN#

Durable, easy-to-use water rescue device with a highly visible orange nylon bag and mesh panels that drain quickly.

PRODUCTS WITH A
MISSION®



NORTH AMERICAN RESCUE®

www.NARescue.com • 888.689.6277