

TRITON SERIES *Pegasus Ropes®*

Specially Designed for Water Rescue Professionals and as a High Quality Tag Line...

Featuring 100% Innegra™ fiber braided core which is the lightest structure fiber available giving Triton additional buoyancy, low elongation and consistent strength. The sheath is made of high quality polypropylene that adds additional flotation and protection to the core. The combination of these materials give you a high strength and durable rope that is soft to the touch and can be easily stored in throw or rope bags. Triton is also used as a tag line for rescue operations.

Pegasus Ropes® cores are all designed with Innegra™ S, a new and innovative advanced fiber that gives Pegasus Ropes® the same physical & mechanical properties – whether wet, dry or even exposed to chemicals. This breakthrough technology has an impressive strength-to-weight ratio, making it the lightest structural fiber available today. Innegra's unique composition also provides great thermal properties when used in hot or cold environments. For the first time you can be confident that the backbone of your rope's system, your core, will perform regardless of environmental challenges.

Colors Available:

- 7.5mm Yellow with Green Runner and Reflective Tape (Item# 90-0303)
- 7.5mm Red with Yellow Runner (Item # 90-0305)



NORTH AMERICAN RESCUE®
www.NARescue.com • 888.689.6277



RESCUE

Triton Series™ Pegasus Ropes®

Dia.	Color	Runner	Item#	NSN#
7.5mm	YEL	GRN/RFL	90-0303	
7.5mm	RED	YEL	90-0305	

*10% lighter & 250% stronger than
polypropylene alone - specially designed for
water rescue professionals*

PRODUCTS WITH A
MISSION®

Features:

- High quality, multipurpose rope featuring a 100% Innegra™ fiber braided core with a high twist polyester sheath for superior performance
- Excellent knot-ability with high strength-to-weight ratio & low stretch/sheath slippage – wet, dry or in any other climatic condition
- Ultra-lightweight, strong Innegra™ core for reliable strength, durability & flotation
- Physical & mechanical properties remain unchanged even when wet, dry or contaminated with chemicals
- Soft to the touch, easily stored and deployed from stuffed sack
- Low dielectric & UV stable

Warhorse 9.5mm Rope Specifications:

- Diameter: 9.5mm
- Weight: 3.34 lb per 100 ft
- Tensile Strength: 5,100 lbf (22.7 kN)
- Fibers (core/sheath): Innegra™/Polyester
- Sheath Ratio: 28% Polyester
- Ratings: NFPA 1983/2012 Throwline (Pending)

Warhorse 9.1mm Rope Specifications:

- Diameter: 9.1mm
- Weight: 4.88 lb per 100 ft
- Elongation: 1.7%
- Tensile Strength: 5,670 lbf (25.2 kN)
- Fibers (core/sheath): Innegra™/Polyester
- Sheath Ratio: 63% Polyester
- Ratings: NFPA 1983/2012 Throwline (Pending)

STRENGTH
that DEFIES GRAVITY™



NORTH AMERICAN RESCUE®

www.NARescue.com • 888.689.6277