

# NITRO STRIKE

Fire Suppression **RESCUE**

**NitroStrike™ Nitrogen Foam System** is a new, patented CAFS (Compressed Air Foam System) technology that brings increased capabilities and performance in a cost effective solution. Our unique blending system generates a more durable bubble matrix, allowing better adhesion to surfaces and more effective fire suppression. Additionally, NitroStrike™ maximizes foam expansion rates and bubble durations for optimized fire fighting, meeting NFPA standards. Our systems allow the use of all foams, including decontamination solutions, without the need to modify the base system.

NitroStrike™ reduces mechanical complexity by blending foaming agents at the manifold without moving parts. This provides the added durability required by extreme operational environments and reduces long-term maintenance costs.

*NOTE: Systems not charged, must be filled & charged by end users.*

- Shaving cream-like consistency for better adhesion to surfaces
- No moving parts in the mixing system
  - NFPA Rated 2A/10B (2.5 Gallon) | 10A/40B (30 Gallon)
  - Fast re-servicing in the field
- Use low cost training solutions for inexpensive exercises
- Single device configuration allows the use of AFFF (Aqueous Film Forming Foam) concentrate and decontamination solutions\*
- Adjustable foam mixing (30/60 Gallon)
- Narrow for easy storage/maneuverability
- Compatible for use with Nitrogen or Compressed Air\*\*

**No moving parts in  
the mixing system...**



**NORTH AMERICAN RESCUE®**

[www.NARescue.com](http://www.NARescue.com) • 888.689.6277

\* AFFF freeze protect solutions should be utilized when conditions are below freezing.

\*\* Conversion fitting required for compressed air use sold separately