

TACTICAL RESPONDER VEST MKII *with Side Armor*

REV2018-09-19

Personal State-of-the-art Ballistic Protection...

The Tactical Responder Vest MKII with Side Armor provides state-of-the-art ballistic personal protection with one of the largest NIJ 0101.06 Level IIIA front/back panel soft armor protection systems available in the industry - Front/back panel protection area: 187 sq. in. (W 11 in. x H 17 in.). The vest comes with built-in front and back hard armor plate pouches to allow the option to upgrade up to various sizes of Level IV hard plate protection (plates sold separately). The ballistic soft armor is comprised of a unique, multi-hit capable, patent-pending assembly of ballistic materials that capture projectiles and disperse the energy over the entire surface of the panel. This vest includes the optional cummerbund-style side Level IIIA soft armor (coverage area: H 7 in. x L 62 in.) with the capability of additional plate pouches (sold separately) that has the capability of adding additional lateral protection via side plate pouches (sold separately) to accommodate hard side plates (not included). This full configuration offers Level IIIA soft armor front, back and side ballistic protection that has the capability to be upgraded with Level IV hard plates (not included).

This "one-size-fits-most" soft armor ballistic vest easily adjusts at the shoulder and waist to fit different size rescuers. The front, back, and side panels as well as the shoulder straps have MOLLE capability that allows for the attachment of additional medical or extraction equipment as needed.

Technical Specifications:

- Complies with and exceeds NIJ Ballistic Resistance Standard 0101.06 for ballistic performance of Level IIIA body armor
- Front and back hard armor plate pouches for increased protection (plates not included)
- Front/back panel protection area: 187 sq. in. (W 11 in. x H 17 in.)
- Proprietary assembly of ballistic materials
- Includes cummerbund-style Side Armor Protection (coverage H 7 in. x L 62 in.) with the capability of additional plate pouches (sold separately)
- Ballistic Vest Weight: Less than 13 lb
- Upgradeable to Level III/IV protection with the addition of hard plates and plate pouches (not included)



*"RESCUE TASK FORCE"
Placard and Side Armor Plate
Pouches sold separately*

RED
BLK
YEL
COY
BLU

Tactical Responder Vest MKII with Side Armor

Color	Item #	NSN#
RED	70-0045	
YEL	70-0046	
BLK	70-0019	
COY	70-0020	
BLU	70-0097	



NORTH AMERICAN RESCUE®

www.NARescue.com • 888.689.6277

PRODUCTS
WITH  **MISSION®**

TACTICAL RESPONDER VEST MKII *with Side Armor*

REV2018-09-19

Features:

- NIJ 06 Level IIIA Soft Armor Ballistic Protection
- Front and back hard armor plate pockets able to receive multiple size plates
- Includes cummerbund-style Side Armor Protection (coverage H 7 in. x L 62 in.) with the capability of additional plate pouches (sold separately)
- Mil-Spec industrial reinforced webbing
- Front and back MOLLE modular attachment system (PALS compatible)
- Durable 1,000-denier Cordura nylon external carrier construction
- Adjustable hook and loop side straps – expandable up to 62 in.
- Rescue Handle – 1,200 lb tensile strength reinforced strap
- One of the largest soft armor coverage areas in the industry - Front/back panel protection area: 187 sq. in. (W 11 in. x H 17 in.)
- Adjustable hook and loop padded shoulder straps with MOLLE plus two fixed “D” rings
- 5-year manufacturer’s warranty
- Blast mitigation configuration
- Made in the USA

Dimensions:

- Vest with Side Armor (stored): H 19 in. x W 13.5 in. x D 1 in.
- Front & Back Soft Armor coverage: H 17 in. x W 11 in.
- Cummerbund coverage area: H 7 in. x L 62 in.
- Maximum Waist Measurement: 62 in.
- Total Weight: 10 lb 9 oz



“RESCUE TASK FORCE” Placard and Side Armor Plate Pouches sold separately



NORTH AMERICAN RESCUE®

www.NARescue.com • 888.689.6277

PRODUCTS
WITH  **MISSION®**