

# BATLSKIN VIPER P2 HELMET

REV022019



## **Cost effective ballistic and head impact protection...**

The premium, lightweight ACH built to exact military specs, exceeding U.S. Army ACH impact standards and tested with multiple hits and across all temperature ranges. Advanced composite shell with Ultra-High-Molecular-Weight Polyethylene ballistic core achieves weight reduction while delivering advanced ballistic (NIJ IIIA) and impact protection.

Features the Modular Suspension System with simple one-handed Dial Ratchet Mechanism to modify the fit band and adjustable crown net for cooling comfort and low pressure wear.

### **Features:**

- 4-point integrated harness with unique buckle system (no loose straps)
- Exceeds U.S. Army ACH impact standards and tested with multiple hits and across all temperature ranges
- Stops NIJ IIIA level threats
- Hybridized layer construction with an Ultra-High-Molecular-Weight

### **Shell Geometry and Construction:**

- Hybridized layer construction with an Ultra-High-Molecular-Weight Polyethylene (UHMWPE) ballistic core
- Low profile design/Designed for comfort
- Offers unsurpassed impact protection and ballistic rated hardware
- Tested for ballistic performance from -40 °F to 158 °F

### **Modular Suspension System:**

- 4-point integrated harness with unique buckle system (no loose straps)
- Low profile ballistic bolts
- Dial Ratchet Mechanism adjusts the fit band (simple one-handed operation)
- Infinitely adjustable nape pad to ensure helmet stability
- Adjustable crown net for sweat wicking, comfort and low pressure wear

### **Impact Liner:**

- Low profile impact material does not contact the head in normal operation
- Provides a free flow of air to aid in cooling
- Exceeds U.S. Army ACH impact standards and tested with multiple hits and across all temperature ranges

### **Dimensions:**

Weight: 2.5 lb

### **Batlskin Viper P2 Helmet**

Size	Color	Item #	NSN#
Medium	BLK	70-0034	
Large	BLK	70-0035	
X-Large	BLK	70-0036	



**NORTH AMERICAN RESCUE®**

[www.NARescue.com](http://www.NARescue.com) • 888.689.6277

**PRODUCTS**  
WITH A  
**MISSION®**